


## 7.0 EXPLODED DIAGRAM &amp; PARTS LIST



No.	Part No.	Part Description	No.	Part No.	Part Description
1	X4001.10	Air cap set, 1.0	12	X4012	Air valve
	X4001.12	Air cap set, 1.2	13	X4013	Air valve spring
	X4001.13	Air cap set, 1.3	14	X4014	Fluid adjustment guide set
	X4001.14	Air cap set, 1.4	17	X4017.10	Fluid needle, 1.0, 1.2
	X4001.16	Air cap set, 1.6		X4017.13	Fluid needle, 1.3, 1.4, 1.6
	X4001.18	Air cap set, 1.8		X4017.18	Fluid needle, 1.8
2	X4002.10	Fluid nozzle, 1.0	18	X4018	Fluid needle spring
	X4002.12	Fluid nozzle, 1.2	19	X4019	Fluid adjustment knob
	X4002.13	Fluid nozzle, 1.3	20	X4020	Trigger pin
	X4002.14	Fluid nozzle, 1.4	21	X4021	Trigger
	X4002.16	Fluid nozzle, 1.6	22	X4022	E-Clip
	X4002.18	Fluid nozzle, 1.8	23	X4023	Air inlet
3	X4003	Spray gun body	24	X4024	Air control set
4	X4004	Fluid inlet	25	X4025	Needle packing
5	X4005	Pattern adjustment set	26	X4026	Spring
6	X4006	Air valve shaft	27	X4027	Needle packing screw
7	X4007	Teflon seal	28	X4028	Air cap Teflon seal
8	X4008	Air valve seal set			