



# Grex P635L 1-3/8" 23 Gauge Headless Pinner w/ Auto Lock-Out

## PARTS LIST

Ref. No.	Part No.	Description
1	99006	Hex. Soc. Head Screw
2	97002	Spring Washer
3	63500	Cap & Gasket
3-1	63523	Cap Gasket
4	63002	Compression Spring
5	63003	Valve Stop (Seal)
6	63501	Cylinder Cap
7	96649	O-Ring
8	96631	O-Ring
9	96632	O-Ring
10	63005	Head Valve
11	96633	O-Ring
12	96059	O-Ring
13	63006	Cylinder Bushing (Collar)
14	96634	O-Ring
15	63502	Piston Ram Assembly
16	63503	Cylinder
17	63009	Bumper
18	63524	Gun Body
19	63011	Driver Seal (Ram Guide)
20	96650	O-Ring
21	63505	Rear Exhaust Seal
22	96636	O-Ring
23	96012	O-Ring
24	63013	Trigger Valve Seat

Ref. No.	Part No.	Description
25	63014	Trigger Valve Stem
26	63015	Trigger Valve Guide
27	63016	Trigger Spring
28	63017	Primary Trigger Pin
29	95001	E-Ring
30	63506	Primary Trigger
31	63019	Safety Trigger Spring Pin
32	63020	Safety Trigger Spring
33	63507	Safety Trigger
34	63022	Safety Trigger Lock Pin
35	G1-20M-1	Swivel Air Coupler
36	92002	Lock Nut
37	63508	Support
38	88005	Hex. Soc. But. Head Screw
39	97001	Spring Washer
40	99004	Hex. Soc. Head Screw
41	99002	Hex. Soc. Head Screw
42	63509	Nose Cover Plate
43	63510	Guide Plate (Nose)
44	63525	Magazine
45	63512	Spacer Plate
46	63513	Railing Plate
47	99631	Hex. Soc. Flat Head Screw
48	63526	Magazine Cover
49	63515	Pusher Stop

Ref. No.	Part No.	Description
50	63516	Magazine Latch Spring
51	63032	Pusher #1 (S)
52	63033	Pusher #2 (L)
53	63034	Pusher Spring
54	63527	Pusher
55	63517	Magazine Rear Cap
56	63518	Magazine Latch
57	88001	Hex. Soc. But. Head Screw
58	88017	Hex. Soc. But. Head Screw
59	89003	Washer
60	63519	Spring Pin
61	63520G	No Mar Rubber Tip
62	AW03S	Allen Wrench
63	68035	Edge Guide Holder
64	68034	Belt Hook
65	88008	Hex. Soc. But. Head Screw
66	88017	Hex. Soc. But. Head Screw
67	99012	Hex. Soc. Head Screw
68	63528	Lock-Out Cover
69	63529	Lock-Out Lever
70	63530	Lock-Out Spring
71	63531	Lock-Out Pin
72	95003	E-Ring
73	FT001	Edge Guide